

Hybrid Multi-Pump Dip Switch Settings

SW1		1	2	3	4
Channel 1 Address	1	OFF	OFF	OFF	OFF
	2	ON	OFF	OFF	OFF
	3	OFF	ON	OFF	OFF
	4	ON	ON	OFF	OFF
	5	OFF	OFF	ON	OFF
	6	ON	OFF	ON	OFF
	7	OFF	ON	ON	OFF
	8	ON	ON	ON	OFF
	9	OFF	OFF	OFF	ON
	10	ON	OFF	OFF	ON
	11	OFF	ON	OFF	ON
	12	ON	ON	OFF	ON
	13	OFF	OFF	ON	ON
	14	ON	OFF	ON	ON
	15	OFF	ON	ON	ON
	16	ON	ON	ON	ON

SW1		5	6	7	8
Channel 2 Address	1	OFF	OFF	OFF	OFF
	2	ON	OFF	OFF	OFF
	3	OFF	ON	OFF	OFF
	4	ON	ON	OFF	OFF
	5	OFF	OFF	ON	OFF
	6	ON	OFF	ON	OFF
	7	OFF	ON	ON	OFF
	8	ON	ON	ON	OFF
	9	OFF	OFF	OFF	ON
	10	ON	OFF	OFF	ON
	11	OFF	ON	OFF	ON
	12	ON	ON	OFF	ON
	13	OFF	OFF	ON	ON
	14	ON	OFF	ON	ON
	15	OFF	ON	ON	ON
	16	ON	ON	ON	ON

	SW2	1	2	3	4	5	6	7	8
Pump Brand	NO PUMP (Demo)	OFF	OFF	OFF	OFF	OFF	---	---	---
	GILBARCO	ON	OFF	OFF	OFF	OFF	---	---	---
	WAYNE	OFF	ON	OFF	OFF	OFF	---	---	---
	TOKHEIM	ON	ON	OFF	OFF	OFF	---	---	---
	BENNETT RS485	OFF	OFF	ON	OFF	OFF	---	---	---
	PMC	ON	OFF	ON	OFF	OFF	---	---	---
	DEER	OFF	ON	ON	OFF	OFF	---	---	---
	KRAUS	ON	ON	ON	OFF	OFF	---	---	---
	TATSUNO	OFF	OFF	OFF	ON	OFF	---	---	---
	DONG HWA	ON	OFF	OFF	ON	OFF	---	---	---
	NUOVO PIGNONE	OFF	ON	OFF	ON	OFF	---	---	---
Operation	Clear Prices on Power Up	---	---	---	---	---	---	ON	---
	Normal Operation	---	---	---	---	---	---	OFF	---
Interface Type	RS232 type I/O	---	---	---	---	---	---	---	ON
	RS485 type I/O	---	---	---	---	---	---	---	OFF

Notes on Operation:

1. All dispensers need to be addressed for fueling position 1 or 1 & 2 depending on the number of fueling positions in the physical dispenser.
2. Only Kraus 500 dispenser heads are supported and the Pump ID needs to be set to 1.
3. Cannot handle Cash/Credit pricing at this time. Cash and Credit prices must be the same.