

Picon II Quick Reference for Operators

Operator Sales Sequences		Active Operator Keys	
AUTHORIZE		<PUMP>	Select pump #
Post Pay	Press <PUMP #> Press <AUTHORIZE>	<AUTHORIZE>	Authorize or resume a pump
Preset Post Pay	Press <PUMP #> Enter amount on keypad Press <AUTHORIZE>	<CASH PAID>	Pay out a cash sale
Prepay	Press <PUMP #> Enter amount on keypad Press <CASH PAID> or <CREDIT PAID> Press <AUTHORIZE>	<CREDIT PAID>	Pay out a credit sale
PAY OUT A SALE		<VOLUME>	Display sale volume
Press <PUMP #> Press <A/B> if stacked sale Press <CASH PAID> or <CREDIT PAID>		<PPU>	Display sale PPU
REFUND CHANGE FROM PREPAY		<A/B>	Toggle between A & B sale
Press <PUMP #> Press <A/B> if stacked sale Press <CHANGE>		<PUMP STOP>	Stop one pump (first, press pump # to stop)
PRINT A RECEIPT		<PUMP STOP>	Stops all pumps for emergency (press and hold 5 seconds)
Press <PUMP #> Press <A/B> if stacked sale Press <PRINT>		<PRINT>	Print a receipt
		<CHANGE>	Show change due from a prepay sale (press twice to display prepay amount)
		<MANAGER>	Enter & exit Program & Report modes
		Special Functions — Press <SELECT>	
		<SELECT>	Show time/date
		<PUMP STOP>	Turn console off
		<ENTER>	Show shift totals
		<CHANGE>	Change shifts
		<PRINT>	Print shift report
		<00>	Print Help sheet with all function operations

Plcon II

Quick Reference for Operators

Plcon II Special Select Functions (To enter Special Functions and access features, press <SELECT>)	
Time/Date	Press <SELECT> again Press <CLEAR> to exit
Turn Console Off	Press <PUMP STOP> Enter PIN Code to turn back on
View Current Shift Totals by Product	Press <ENTER> Press <VOLUME> to see total volume Press <CASH PAID> for cash total Press <CREDIT PAID> for credit total Press <ENTER> for next product
Print Current Shift Report	Press <PRINT>
Change Shift	Press <CHANGE> (only after viewing the totals or after report printing is completed) Note: The Change Shift function may be utilized only after the totals have been viewed and printed and may be accessed only once every hour.

Progressive International Electronics, Inc.

1106 G Great Falls Court • Knightdale, NC 27545 • Phone 919 266-4442

Plcon II Quick Reference for Managers

Plcon II Program & Setup Modes Available to Managers Only

- To access Program & Setup Modes, press <MANAGER>
- Enter Manager PIN Code (default — 2422)
OR Enter Programming PIN Code (month times day plus year)
- Press <ENTER> (display will show MGR 0 or PGM 0)
- Press Mode #, followed by <ENTER> to select mode
OR Press <MANAGER> to exit to normal Operator functions

MODE	FUNCTION
PGM 1	Program Dispenser Type
PGM 2	Program Dispenser Information Program Product Assignments, Full/Self Service, Blend Ratio for each pump
PGM 3	Program Product Name
MGR 1	Program Cash & Credit Price
PGM 60	Program Pump Specific Settings (if available)
MGR 5	Program Time & Date
MGR 6	Program Beeper Options Program beeper options for Handle, Collect, Drive Away
PGM 13/ MGR 7	Program Operator PIN Code Program Manager PIN Code (Save new code #(s) in safe place; access is not possible without proper codes)
MGR 4	Clear Resettable Totals

Plcon II Quick Reference for Managers

Plcon II Reports Available to Managers and Operators

- To access Reports, press <MANAGER>
- Enter Manager PIN Code (default — 2422)
OR Enter Operator PIN Code (default — 1111)
- Press <ENTER> (display will show MGR 0 or OPR 0)
- Press Mode #, followed by <ENTER> to select mode
OR Press <MANAGER> to exit to normal Operator functions

MODE	FUNCTION
MGR 2/ OPR 1	Read Reports 1 Resetable Totals 2 Non-Resetable Totals 3 Shift 1 Totals By Product (previous shift) 4 Shift 2 Totals By Product (second previous shift) 5 Shift 3 Totals By Product (third previous shift) 8 Polled Pump Totals
MGR 3/ OPR 2	Print Reports 1 Resetable Totals 2 Non-Resetable Totals 3 Shift 1 Totals By Product (previous shift) 4 Shift 2 Totals By Product (second previous shift) 5 Shift 3 Totals By Product (third previous shift) 8 Polled Pump Totals 12 Console Program Information 14 Program Print Header